


Using NetPiano with Roland RG-7

You can enjoy NetPiano online library with Roland Digital Grand RG-7.


If you prepare additional external speakers, you can also make the backing orchestral sounds play from those external speakers.

Connection



Operation

1. Press the [Function] button, getting its indicator to light.
2. Press the [Select -] button or [Select +] button to display the AUX INPUT screen.
3. Press the [Select -] button or [Select +] button so "Mode" is flashing.



4. Press the [Value -] button or [Value +] button to set the mode to "Decode."

* If you often use NetPiano with your RG-7, it will be convenient for you that you memorize this setting by the MEMORY BACKUP function. Refer to RG-7 owner's manual for the detail.

5. Press [Song] button on the panel or [EXTERNAL] button on the remote, to select the song category "Aux Input."
6. Start playback on your NetPiano Player.

RG-7 will start to play along with the backing orchestration.

You can turn on and off the moving key by pressing [Moving Key] button.

You can adjust the total sound level by the panel volume.

You can also adjust the backing sound relative level by "Level" value in the above AUX INPUT screen.